


Balanced Vertical Slider or Tilt To Wash BVS

Balanced Vertical Slider

With Spring Balances



1. Measure from wall D to wall C and minus 10mm
2. Measure from wall A to wall C and minus 10mm
3. Measure from wall A to the centre of B and minus 5mm

When ordering, make sure you quote either: BVS or Tilt to Wash

1. Measure from wall D to wall C and minus 10mm
2. Measure from wall A to wall C and minus 10mm
3. Measure from wall A to the centre of B and minus 5mm

When ordering, make sure you quote: BVS or Tilt to Wash

Please do not include attachments with your email. All we require is your width and height sizes, styles and quantities. Please just write these in the body of your email.

BVS Offset Panels

How do I get a Quotation for Secondary Glazing?

In order to obtain a quotation for secondary glazing you need to email us with - widths x heights x style (e.g. two panel vertical slider, three panel horizontal slider, hinged unit etc) as per the measuring instructions.

You would be well advised to have a good look at the secondary glazing options available and which of those suits your requirements for the final operation of the products.

If you require assistance call **01325 310520**. Please Note: **Quotations are only available via e-mail**, however you can have as much technical advice via telephone from our technical department, who are always happy to help